

OBDII Plug and Play GPS Tracker



Features:

Plug-and-play OBDII GPS tracking device with backup battery for real-time vehicle and fleet management


- · High-precision GPS tracking device plugs into existing OBDII ports for real-time tracking
- Internal backup battery if the device is removed from power it will continue to track for a period of time
- Speeding, harsh braking and cornering, accident and rollover detection
- Electronic Odometer Calculations
- Accelerometer for adaptive and movement-based tracking
- Plug and play or splitter installation options

Installation:

1. Provide the IMEI number (15 digits, located on top of the unit) to your Customer Success Officer or email support@locate2u.com

2. Locate the OBDII Port in your vehicle, usually located under the dashboard on the driver or passenger side of the vehicle.

Lဂ္<u>cate</u>2u



- 3. Plug the unit into the port.
- 4. Turn the vehicle on, the blue and red lights on the unit should start flashing quickly (1 second per flash).
- 5. The vehicle needs to be driven, in order to connect to the satellite and the server, this can take up to 20 minutes and requires good mobile/cell signal strength.
- 6. Be sure to record the IMEI and the details of the car in the Vehicle Details table at the end of this document to update in Locate2u.

Once the unit is connected, the Locate2u Team Owner should receive an email notifying of the connection (this may go to spam). Data will start appearing in Locate2u.

Troubleshooting

Lights

Blue indicator: online, long blink (over 3 seconds) is valid, short blink (below 3 seconds) is invalid. Red indicator: positioning, long blink (over 3 seconds) is valid, short blink (below 3 seconds) is invalid Green indicator: sleeping/standby

Both lights are flashing slowly but I can't see the device in Locate2u?

Contact support@locate2u.com and provide the IMEI number, this indicates the device hasn't been activated against the account.


Blue light flashing quickly but the red light is flashing slowly and the device isn't showing in Locate2u? Check the Sim Card has been inserted correctly, Gold Plates should be pointing down. If this doesn't resolve the issue, contact support@locate2u.com and quote the IMEI and Sim Card number to the team.



No lights are flashing

Check the device is plugged into the port correctly, if it is please contact support@locate2u.com the unit may need to be replaced.

We are here 24x5 to help you, For any Support Requests please contact **support@locate2u.com** or use the live CHAT SUPPORT button in the system, found in the support menu at the base of the menu bar on the left hand side of the screen. You can also call us at these numbers:



Vehicle Details

Licence Plate/VIN	IMEI	Asset Group Name